


USER GUIDE

PUMPCHECK


1



2



3



4






5



▶x1	ID=0914	☰
▶	14AL	4.537h
1	7.3A	23.975st

▶x2	ID=0914	☰
▶	14AL	4.537h
1	7.3A	23.975st
▶	58AL	5.932h
2	12.7A	52.730st



COUNTERS RESET PUMPCHECK

